

## Container Handler

Used Container Handler Fremont - Container handlers, also known as cargo ships and container ships transport their load in a large intermodal container. This shipping method is known as containerization. They are commonly utilized as a means of commercial freight transport often used to transport non-bulk forms of seagoing cargo. The capacity of container ships is measured in units equivalent to twenty-foot equivalent loads. The majority of typical loads consist of a mix of 40-foot containers and 20-foot containers. Approximately ninety percent of non-bulk cargo across the globe is transported by container ships. Container handlers are one of the biggest vessels sailing and are the main rival for oil tankers on the ocean. Dry cargo is categorized into two main types: break-bulk cargo and bulk cargo. Coal and grain are considered to be bulk cargo items. They are typically transported in their raw form within the hull of the ship, free from packages in immense volume. Break-bulk cargo items normally consist of manufactured goods that are transported in packages. Before containerization was invented in the 50s, break-bulk items were loaded, secured and unlashd one item at a time. Grouping cargo into containers allows for 1000-3000 cubic feet of cargo to be simultaneously moved once every container has been secured with standardization techniques. Overall efficiency has largely increased with break-bulk cargo shipping. It is estimated that shipping time has been reduced by eighty-four percent and costs have been reduced by approximately thirty-five percent. More than ninety percent of non-bulk items were recorded as being transported in containers in 2001. The first cargo ships were born in the 1940s as redesigns from World War II tankers. Container ships eliminate the individual holds, hatches and dividers normal within traditional cargo vessels. Essentially the container ship's hull is similar to a huge warehouse that uses vertical guide rails to divide it into cells. These cells have been designed to transport the cargo in containers. Most shipping containers are constructed from steel; however, additional materials including plywood, fiberglass and wood are used. As containers have been designed to completely transferred to and from coastal carriers, semi-trailers, trucks, trains and more, these containers are categorized due to their function and size. The entire shipping industry has been revolutionized by containerization, although, it did not start out in the easiest manner. Initially, ports, railway companies and shippers were concerned regarding the extensive costs that came with constructing infrastructure, ports and railways required to accommodate the cargo ships and transporting items with rail and roads. There was skepticism regarding potential dock and port worker job loss when containerization was announced for fear that numerous manual jobs would disappear. There was a decade of legal battles prior to the container ships starting international service. By 1966, after the first container liner service began from Rotterdam, Netherlands to the USA, cargo shipping was transformed. Container ships only take a few hours to be loaded and unloaded, compared to the days a traditional cargo vessel required. Cutting labor finances and shortened shipping times between ports has been hugely successful. It only takes a few weeks to deliver items from India to Europe and vice versa, whereas it used to take months previously. There is generally less damage to goods due to less handling. Less cargo shifting during a voyage is also beneficial. Before shipping, containers are closed and only opened after they arrive at their new location to prevent theft and damage. There has been greater international trade growth due to the reduced shipping expenses and travel time delivered by container ships. Cargo that used to arrive in bales, crates, bags, cartons or barrels now arrives in containers sealed from the factory. There is a product code on the contents utilized by scanning machines and computers to trace. Amazingly, technology has advanced with this accurate tracking system to be so exact that a 2-week voyage can be timed for arrival with accuracy less than 15 minutes! Manufacturing times and delivery have been greatly enhanced with these advancements. Raw materials are delivered in less than an hour in sealed containers within an hour prior to being utilized for manufacturing. This results in more accuracy and less inventory costs. Boxes are provided by shipping companies to the exporters to facilitate loading merchandise. They are delivered into the docks by rail or road or a combination of both to be loaded onto container ships.

It used to take huge groups of men and numerous hours to fit cargo into different holds prior to containerization. The ship relies on cranes either on the pier or installed on board to organize the containers accurately. Once the hull has been completely loaded, more containers can be secured onto the deck. Efficiency has been one of the main design elements for cargo ships. Break-bulk ships may carry containers. Designated cargo hold on container ships have been built to increase efficiency during loading and unloading to ensure safe travel. The specialized hatch design allows openings from the main deck to access the cargo holds. These openings are situated along the entire cargo hold breadth, surrounded by a raised steel structure called the hatch coaming. There are hatch covers located on top of the hatch coamings. Until the 1950s, wooden boards and tarps were responsible for securing the hatches and holding down the battens. Hatch covers are made of secure metal plates and cranes are used to lift them on and off of the ship. There are other hatch models that rely on articulated mechanisms that use strong hydraulic rams for opening and closing. Another important cargo ship design feature is cell guides. These vertical structures are made of strong metal that is attached to the cargo hold on the ship. They work by guiding containers into particular rows while loading and help to support items during travel. The design of the container ship uses cell guides enough that the United Nations Conference on Trade and Development utilize them to distinguish between container ships and regular break-bulk cargo ships. There are three dimensions used in cargo plans to determine the position of the container on board the ship. The initial coordinate starts at the beginning of the ship and increases aft. The tier is the second coordinate, with the initial tier starting at the bottom of the cargo holds with the second, tier situated on top of the first and continuing on. The third coordinate is found in the third row. Rows found on the port side of the ship exhibit even numbers and those located on the starboard side are given odd numbers. Rows that are located along the ships' center are designated lower numbers and they increase for locations found further from the center. It is possible for container handlers to carry twenty, forty and forty-five foot containers. The largest size fits only above deck while the 40 foot size makes up for the majority of the load or approximately ninety percent of the container shipping. Approximately 90% of the freight moves across the globe with container shipping. It is estimated that 80% of global freight travels with 40-foot containers.